

TEK TANKS

Fitting Instructions for the Retro Fit Dipstick

Identify a position on the tank top where you would like to place the Dipstick.

Beware of any internal parts like baffles, sender arms or angled pick up pipes.

Drill a hole between 36 and 40mm with a suitable hole saw. A 1 ½" hole saw is 38mm.

Place the Dipstick assembly over the hole. The flanged nut under the mounting plate will sit in the hole you have just drilled. Mark the 5 holes on the mounting plate onto the tank top. Drill these holes 4mm.

Place the gasket on the tank top and then line up the 5 holes on the mounting plate with the 5 holes on the gasket. The holes are not equally spaced.

Screw the plate down onto the tank top using the 5 self tapping screws supplied. These are designed for use on plastic only. Do not over tighten.